

Ref. No.	LGETH -170127-007
Date	Jan. 27. 2017
Rev. No.	Rev.1
Rev. Date	May.28.2021

LG Electronics Inc.

SPECIFICATION SHEET for APPROVAL

MODEL : GVS265PAB (Tropical)

CUSTOMER : EMBRITAL

	APPROVAL
Name	
Date	
AIR CONDITIONER MODEL	

LG Electronics Inc.

	Designed	Checked	Approved
Name	10	Engl	Chalpapan
Date	31 May 2021	31. May. 21	31 May 21
	5	ORIGINAL 310521	

Please Return 1 Copy on Your Approval.

Air Conditioning Compressor Division LG Electronics Inc. Tel : (+66)38 - 923 - 109 Fax : (+66)38 - 923 - 119

	Ref. No.	LGETH -170127-007
	Date	Jan. 27. 2017
	Rev. No.	Rev.1
0.Revision History	Rev. Date	May.28.2021
		

Date	Rev. No	Rev. description	Write
		Page 7/13 -Change sleeve damper from P/N.4816U-L001G→ 4816U-L001H	
28.05.2021		Page 13/13 Revise label format (Refer 4M Change confirm)	Thunyarat D
		Page A-8 -Change sleeve damper from P/N.4816U-L001G→ 4816U-L001H	
		-Revise spec sleeve damper length from 34→37 mm (Actual spec)	

			Ref. No.	LGETH -170127-007
			Date	Jan. 27. 2017
Sne	ecification		Rev. No. Rev. Date	Rev.0
-	ompressor		Nev. Date	<u> </u>
1	Model Name	G	VS265PAB	
2	Compressor Type	Hermetic	Motor Com	pressor
3	Compression Type	Rotary Type	e (Rolling Pi	ston Type)
4	Application	Refrigeration system (Cooling & Heating)		
5	Refrigerant	R410A		
6	Safety Approval		-	
7	Oil / Oil Charging Amount	PVE(FVC	68D) / 540	0 ± 10cc
8	Displacement	20	6.5 cc. / rev	
9	Painting	Blac	ck Color Pai	int
10	Net Weight (Including Oil)	19.9 kg		
11	Suction Tube I.D	Q	ð 16.0 mm	
12	Discharge Tube I.D	Ç	ð 9.7 mm	
		I		

1.2 Motor

Motor Type / Starting Type	Single Phase Induction Motor / PSC		
Pole / Rated Output	2 Pole / 1,980 Watts		
Power Source	1 Ph - 220~240 Volts - 50 Hz		
Rated Revolution	2,842rpm		
Insulation Class	E Class		
Windings Resistance	Main	1.43 ± 7% [Ω]	
(at 25 °C)	Sub	2.22 ± 7% [Ω]	
Locked Rotor Ampere	54 A (at 240 V)		

TH-COMP-ED-095-A4 (13.05.06)

		Ref. No.	LGETH -170127-00
		Date	Jan. 27. 2017
		Rev. No. Rev. Date	Rev.0
3 Wiring diagram			P
Run	ining Capacitor	Compressor	
※ Make Sure to connec	t right way same	with the wiring di	agram.
4 Electrical Component			
Running Capacitor		50 MFD / 400	VAC
Running Capacitor Overload Protector	INTI	50 MFD / 400 ERNAL TYPE (UF	
Overload Protector 5 Performance	INTI	ERNAL TYPE (UF	914SE5245)
Overload Protector 5 Performance Voltage		ERNAL TYPE(UF 220 V	240V
Overload Protector 5 Performance	[BTU/h]	ERNAL TYPE (UF 220 V 22,850	240V 22,950
Overload Protector 5 Performance Voltage		ERNAL TYPE(UF 220 V	240V
Overload Protector 5 Performance Voltage	[BTU/h]	ERNAL TYPE (UF 220 V 22,850	240V 22,950
Overload Protector 5 Performance Voltage Cooling Capacity (-5%↑) Power Input (+5%↓) EER (-5%↑)	[BTU/h] [W]	ERNAL TYPE (UF 220 V 22,850 6,696	240V 22,950 6,725
Overload Protector 5 Performance Voltage Cooling Capacity (-5%↑) Power Input (+5%↓)	[BTU/h] [W]	ERNAL TYPE (UF 220 V 22,850 6,696 2,210	240V 22,950 6,725 2,275
Overload Protector 5 Performance Voltage Cooling Capacity (-5%↑) Power Input (+5%↓) EER (-5%↑) [BTU/w・hr]	[BTU/h] [W]	ERNAL TYPE (UF 220 V 22,850 6,696 2,210 10.34	240V 22,950 6,725 2,275 10.1

		Ref. No. Date	LGETH -170127 Jan. 27. 2017
		Rev. No.	Jan. 27. 2017 Rev.0
		Rev. Date	-
loise & Vibration			
Voltage	9		At 240 V
Sound Level	[dB(A)]		74 Max
Vibration	[µm]		230 Max
Noise &	Vibration Measuring Pc		300mm
300mm	Aicrophone		- A - T - B Microphone
 Measuring points for specified of the second second	(, Y_)		
 Compressor vibration is r contacted compressor 	measured by a vibration \bigcirc ~ \bigcirc	meter whicl	h is
 Test Condition : Standard Condition (Ps) 	s/Pd = 9.12 / 33.45 kg/c	:m²G)	


				Ref. No.	LGETH -170127-007
				Date Rev. No.	Jan. 27. 2017 Rev.0
1.7 Minimum Startir	a Voltac	10		Rev. No.	-
	iy voltag	Je			
Cold Start					
- Temp. Condition : 35°	С			187 Volts N	/lax.
- Balanced pressure : $Pd - Ps \le 0.5 \text{ kgf/cm}^2$					
- Balanced pressure : Pd – Ps = 0 kgf/m²			176 Volts N	Лах.	
1.8 Voltage Range					
at Standard	Condition			187 ~ 264	Volts
at Overload	Condition	1		198 ~ 264	Volts
Test Conditions					
		Stan	dard	Overload	
Con. Temp (°C)		54.4		64.4	
Eva. Temp (°C)		7.2		15.7	
Return Gas. Temp (°C	2)	35	.0	25.0	
Ambient Temp (°C)		35	.0	54.0	
1.9 Others					
Leak Tight Pressure	High	Pressure S	ide	42 kg	f/cm²G
Loak nghi rocoaro	Low F	Pressure S	ide		-
Hydrostatic trength	High	Pressure S	ide	170 kg	gf/cm²G
Pressure	Low F	Pressure Si	ide	69 kgf / ㎝ G	
Insulation Re (with 500V [Tester)		50 MΩ Min.	
Withsta	and Voltag	je		At 2,200 V / 1 Sec. Leakage Current is less than 5 m/	
Residual Moisture	e (Karl Fisl	her Method)	80 m	g Max.
* Resid	ual Impurit	ies		70 m	ng Max
*) Each part was meas	sured sepa	arately			

Ref. No.	LGETH -170127-007
Date	Jan. 27. 2017
Rev. No.	Rev.1
Rev. Date	May.28.2021

2.Delivered Parts List

			Parts Dwg. NO.		
Parts Name	Type(Model)	EA	LG	Su	oply
Compressor	GVS265PAB	1	-	YES	NO
O.L.P	INTERNAL TYPE	-	-	YES	NO
Cover, Terminal	-	1	3550U-L005D	YES	NO
Gasket	-	1	4986UHL004A	YES	NO
Nut, Common	-	1	FAD30241201	YES	NO
Washer, Customized	-	1	FAF30240201	YES	NO
Damper, Rubber	-	3	MCQ61847401	YES	NO
Sleeve, Damper	1	3	4816U-L001H	YES	NO
Bolt, Stud	-	-	-	YES	NO
Washer, Plain	-	-	-	YES	NO
Nut, Hexagon	-	-	-	YES	NO
Capacitor	-	-	-	YES	NO
Screw, Earth	M4*0.7, Length : Max 0.236 [6 mm].	-	-	Yes	No

%) Refer to Attachments (Accessory Parts Drawings.)



* This guide contains many important safety	messages. Always read and obey all safety messages.	Ref. No.	LGETH -170127-007	
		Date	Jan. 27. 2017	
A WARNING You can be ki	illed or seriously injured if you don't follow instructions.	Rev. No.	Rev.0	
3.2 Application Lim	it	Rev. Date	-	
Refrigerant Charge Limit	[SRAC : Cooling pump] 2,030g Max (*K \approx 0.4, **OIL Dilution Rate \approx 0.20) [SRAC : Heat Pump] 1,720g Max (*K \approx 0.5, **OIL Dilution Rate \approx 0.22)			
Liquid Refrigerant Back	System should be designed not to allow the liquid to go back to compressor which cause knocking noise , current increase or undesirable vibration.			
Δ T : Temp. Difference ^o C	Δ T = Case Bottom Temp Condensing Temp. It must be kept Δ T ≥ 5°C			
Pressure Difference in Operating	The Pressure difference in operating shall be 5.0kgf/m² or more, but 3 minutes starting excluded.			
ON/OFF Operation	Each cycle should be at least 6 minutes (ON Time : at least 3 minute,OFF Time : at least 3 minutes)			
Pressure Difference at Starting	When starting, discharge pressure is balanced with suction pressure. (Pd – Ps \leq 0.5 kgf/m ²)			
Tilt in Operation	The allowable tilt of the compressor in operation shall be 5° or less.			
	The Accumulator volume should be e system refrigerant volume.	nough to cove	r 50% of maximum	
	Effective Volume of Accum. × Specific gravity of Refrigerant * K =			
System Accumulator				
	 ※ Effective Volume of Accumulator = 691 (m³) ※ Specific Gravity of Refrigerant (R410A) = 1.2 g/(m³) (at 20°C) 			
	If coefficient "K" does not meet recommendation, refrigerant system must check liquid back phenomenon at accumulator.			
Protecting Reverse Operation	The compressor must be operated by proper voltage in accordance with the frequency without reverse revolution condition. The reverse revolution condition can be avoided by just keeping right order of phase supplied power source.			

A WARNING

Ref. No.	LGETH -170127-007
Date	Jan. 27. 2017
Rev. No.	Rev.0
Rev. Date	-

3.2 Application Limit

Frequency Range	Rated Frequency ±2%
Pipe Stress	Don't allow any force on discharge & suction pipe . The piping stress must be less than 300kgf/ဏ² at starting and stopping. And less than 153kgf/ဏ² at running.
Oil Level	It must be checked oil level by the compressor with sight glass we supply. And oil level must be kept over guide line level **note ² . at any condition.
Protection device	Refrigeration system must has the compressor protection device like over pressure, high temperature, sensing locked pump in the controller. When starting & running fail by abnormal overload, controller must be able to cut off power of compressor before motor burn out.
Pump down refrigerant	If pump down time is too long, compressor can be damaged due to excessive temperature increase or poor lubrication. Guideline of pump down process. - Time : less than 30 seconds - Suction Pressure : It should not run under below 1kgf/m²G. And before closing a service valve, compressor running for more than 5 minutes is recommended.


※ If gas charge amount of refrigerant specified is exceeded,

both parties should discuss the matter to determine compressor specification. (accumulator volume, lubricating oil amount) and system specifications (crank case heater, oil separator, additional accumulator, etc)

Ref. No.	LGETH -170127-007
Date	Jan. 27. 2017
Rev. No.	Rev.0
Rev. Date	-

3.3 Process Limit

Use defined Refrigerant and oil	Any process in where the HCFC's refrigerant or the different kind of oil against the defined. Compressor oil are mixed should be avoided.
Avoid Damage running	The running operation that inspection and the protector inspection that affect a damage to the function and durability of the compressor should be avoided
Running dummy indoor	When the outdoor unit is operated with the indoor dummy unit, the discharged oil should be recovered enough
Prevent oxidation in pipe	Always purge the system and the compressor with the dry nitrogen in order to prevent oxidation of the piping
Charging Refrigerant	When charging refrigerant into the cycle, make sure that refrigerant always be filled from the higher pressure side (condenser exit) of the cycle. If liquid refrigerant is sucked in to the compressor liquid compression occurs, The discharge valve is damaged, lubrication effectiveness degenerates and reliability drops noticeably
Avoid Vacuum running	Do not operate the compressor in a vacuum state. Furthermore do not apply high voltage to a vacuum state compressor. There is a danger that insulation could degenerate, causing electric shock
Avoid Air compression	Do not compress the air including the case of leakage in the refrigeration cycle. If compressors run with air mixed, inside the compressor is heated and pressurized , which may cause an explosion
Promptly Assemble compressor in line	After removing rubber plugs from compressor tubes, Promptly use the compressor. And do not leave in the atmosphere for 10 minutes over. If Air gets into the compressor, accelerating degeneration of the inside of the cycle or compressor
Wiring	Wires connected to the compressor, follow the compressor specification manual and instructions
Storage temperature	-10°C ~ 65°C



		Ref. No.	LGETH -170127-007
		Date	Jan. 27. 2017
		Rev. No.	Rev.1
* LABEL *	\wedge	Rev. Date	May.28.2021
	66		
[UNIT : mm]	GVS265PAB $$ C C THERMALLY PROTECTED R410A 1PH 50Hz 220-240V ~ LRA 54 SERIAL NO.	₹ •	
	Bar Code		
		· [
	Senice should be performed by trained personnel only. Entretien à réaliser par du personnel qualifié.		
	ELECTRIC SHOCK HAZARD -Ground the equipment securely. -Tum off the power before servicing. -Mount the terminal cover in place. -Motivate cache-bomis en place		
	BURN HAZARD RISQUE DE BRÚLURE -Do nottouch with bare handsNe touchez pes à mains nues.	E.	
	EXPLOSION OR FIRE -Var protective goggles. -Do not compress air. -Use specified refrigerant & oil. -Use specified refrigerant & oil. -Use specified refrigerant & oil.	J	

All safety messages will identify the hazard, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed. You are strongly advised to follow these safety instructions.



This is the Safety alert symbol. It indicates a hazardous situation which, if not avoided, could result in death or serious injury.



This is the Electric shock hazard symbol. It indicates a hazardous situation which, if not avoided, could result in the electric shock.



This is the Getting burnt symbol. It indicates a hazardous situation which, if not avoided, could cause fire.



This is the Explosion or Fire symbol. . It indicates a hazardous situation which, if not avoided, could cause explosion or fire.

*1. Effective Period of This Document *


This document will be effective after LG's receipt with your authorized signature. When design modification is approved by the customer , the current document is unavailable.


*2. Compressor operating range *


The Compressor can operate within the limits of the outlined area. Outside these operating fields, the system cause early defects in the compressor. The compressor defects caused by applications operating outside the outlined area will not be considered under the warranty. If the appliance be operated out of the operating range, it must be agreed with the supplier.


Attachment


		PAGE
1. Compressor Drawing	•	A- 1
2. Accessory Fitting	•	A-2
3. Part Drawings.	•	A-3 ~ A-8
4. OLP Characteristic Curve	•	A-9
5. Guideline for using R410A	•	A-10























Guideline of using R410A

Process Control

1. Residual Moisture

Moisture control of lubricant is very important, because hydrolysis of lubricant causes many problems.

2. Residual Chlorine

Chloric furuoro carbon and solvent cause decomposition of oil, no chlorine is recommended (if impossible, below 100 ppm)

3. Contamination Control

Contamination accelerate wear of compressor parts and decomposition of oil. Therefore contamination control must be required.

4. Compressor Sealing

It is recommended to assemble compressor within **5 minutes** after removing sealing cap of compressor.

5. Tube Connection

When brazing welding for tube connection, no use of Flux is recommendable.

Facilities

1. Vacuum Pump Below 0.5 torr vacuum rate is recommendable.

2. Charging System An exclusive charging equipment is necessary.

LG Electronics Inc.